

1a

1b

1. Assembling the pump
Wash the complete pump before first time use.

Push the Dome (7299) into the Pumphousing (7666). Moisten the dome in order to make the assembly easier. Make sure the dome is pushed all the way into the pumphousing. When pumping very thick and oily products (e.g. mayonnaise), the dome may start sliding out of the pumphousing, due to the increased pressure build-up inside the pumphousing. However, this can be prevented by using the optional Clip (7868). Attach the Clip by sliding it around the dome and part of the pumphousing, starting from the inlet-side, making sure that the tab of the dome goes into the slot of the Clip. Push the Tube (7866) on to the tube of the pumphousing. Make sure the pins of the pumphousing catch the notches of the hose. Push the Connector (9472) on to the tube. The pump comes with the 3-lobe Nozzle (7914). Put the nozzle into the spout of the pumphousing. Then fasten the loop of the nozzle to the pin of the pumphousing. To prevent dripping from the 3-lobe Nozzle, put the O-ring into the three notches of the nozzle (see picture 1b).

4. Using the pouch clips
 Flake down the product of the upper end of the pouch. Put the lip of the pouch into the clip inside the container and then close the clip. This will locate the pouch in an upright position while being emptied, to ensure a good product-yield.



4

5. Attaching the Lid
 Lower the lid onto the housing while holding back the handle. When the lid is in line with the housing you are ready to pump.



5

2. Connecting the pouch

Put a new pouch on a flat surface. Locate the fitting. Place the connector of the pump in the centre of the fitting. Firmly push the connector into the fitting until it snaps in place.



6




3

3. Inserting the pouch
 Hold the pump and the pouch with both hands. Let the pouch slide into the container and guide the pump-housing into the slots inside the container.



7. Cleaning
 Detach the dome from the pumphousing by pulling the flap of the dome. Twist and pull the hose off from the pumphousing and the connector. Pull the nozzle out of the pumphousing. Wash the parts by hand, using ordinary detergent. Reassemble according to the instruction "1. Assembling the pump"



7